



## Alternator

### Alternator Removal


#### NOTE

○ Do not remove the alternator to remove the rectifier, regulator, and carbon brush assembly. They can be removed after removing the alternator cover.

- Remove the following.
  - Fuel Tank (see Fuel System chapter)
  - Left Lower Fairing (see Frame chapter)
  - Alternator Lead Connector [A]
  - Water Pump Pipe and Hose
  - Clutch Slave Cylinder (see Clutch chapter)
- Remove the alternator mounting bolts [A].




- Detach the alternator [A] from the engine and then pull out the upper right mounting bolt [B].



### Alternator Installation


- When installing the alternator, clean the alternator legs [A] and crankcase [B] where the alternator is grounded.
- Apply a small amount of engine oil to the O-ring [C].
- Tighten the alternator mounting bolts.
- The lower mounting bolt is shorter than the two upper mounting bolts.

**Torque – Alternator Mounting Bolts: 25 N-m(2.5 kg-m, 18.0 ft-lb)**



### Alternator Disassembly

- Remove:
  - Alternator (see Alternator Removal)
  - Screws [A] and Alternator Cover [B]





- Remove:
  - Brush Assembly [A]
  - Rectifier [B]
  - Regulator [C]
- Unsolder [D] the leads on the rectifier.


**CAUTION**

When unsoldering the alternator leads on the rectifier terminals, do it quickly. If high temperatures are applied for more than a few seconds, the rectifier's diodes may be damaged.


- If it is necessary to remove the carbon brush, unsolder the brush lead [A].



- Remove the alternator coupling to disassemble the rest of the parts as follows.
- Hold the alternator with a vise and remove the coupling nut [A] and coupling [B].




- Unscrew the alternator assembly nuts [A].
- Remove the alternator frame [B].




- ★ If the alternator frame [A] is difficult to remove, use the crankcase splitting tool assembly [B].

**Special Tool – Crankcase Splitting Tool Assembly: 57001-1362**


- Be sure to put a washer (O.D. 12 × I.D. 6 mm) [C] on the alternator rotor [D] to prevent its damage.
- Screw the 5 mm bolts all the way.
- Tighten the center bolt on the special tool to split the alternator halves.
- Once the alternator is split, remove the special tool, and remove the alternator frame.




- To remove the frame ball bearing [A] from the alternator rotor [B], use a suitable bearing puller [C].
- Discard the frame ball bearing.



- Press out the alternator rotor [A] from the alternator housing [B].




- Remove:
  - Screws [A] and Bearing Retainer [B]
  - Housing Bearing [C]
  - Bearing Holder
- Remove the oil seal using the bearing driver set.
- Special Tool – Bearing Driver Set: 57001-1129
- Discard the housing bearing and oil seal.



#### Alternator Assembly


- Install the oil seal [A] using the bearing driver set.
- Special Tool – Bearing Driver Set: 57001-1129
- Install:
  - Bearing Holder [B]
  - Housing Bearing [C]



- Install the bearing retainer with its mounting screws.


**Torque – Alternator Bearing Retainer Screws: 2.5 N-m (0.25 kg-m, 22 in-lb)**

- Position the new housing ball bearing [A] so that the inner race is seated on a suitable press fixture [B].
- Press [C] the alternator rotor [D] into the housing ball bearing.



- Press the new frame ball bearing [A] and bearing covers [B] onto the rotor shaft. The wide band [C] on the outer race goes up.

- [D] Ring
- [E] Alternator Housing
- [F] Press Fixture




- Position the frame ball bearing ring [A] so that the ring projection [B] almost aligns with the groove chamfer [C] where the groove is the deepest. This makes alternator frame installation easier.
- Press in the oil seal so that the spring band faces out and the seal end is flush with the end of the hole.


Eccentric Ring Groove [D]

- Install the alternator frame on the alternator rotor.
- Tighten the alternator assembly nuts.

**Torque – Alternator Assembly Nuts: 4.4 N-m (0.45 kg-m, 39 in-lb)**



- Solder the carbon brush lead [A] with the brush holder as shown.



- Run the alternator leads [A] into the grooves [B] as shown.



**CAUTION**

When soldering the alternator leads to the rectifier terminals, do it quickly. If high temperatures are applied for more than a few seconds, the rectifier's diodes may be damaged.

**Torque – Alternator Regulator Screws, Alternator Brush Screws, and Alternator Lead Terminal Screws: 3.4 N-m (0.35 kg-m, 30 in-lb)**

- Fit the projection [A] of the alternator cover in the alternator frame groove [B].

**Torque – Alternator Cover Screws: 3.4 N-m (0.35 kg-m, 30 in-lb)  
Alternator Coupling Nut: 54 N-m (5.5 kg-m, 40 ft-lb)**

**Operational Inspection**


For any charging system problems, always check the charging system wiring first (see Wiring Inspection), and then check the system with the following tests shown in the troubleshooting guide.

**Troubleshooting Guide**

Test No.	Trouble	Symptoms
1	Battery discharged	Starter not rotating
2	Battery overcharged	Electrolyte level lowering quickly
3	Noise	Alternator or alternator chain noise


**Test No. 1-Battery Discharged**

- Remove:
  - Left Lower Fairing (see Frame chapter)
- Remove the screws holding the alternator cover [A], and take off the cover.
- Check that the alternator leads and connectors are in good condition.
- ★ If not, repair or replace the damaged parts.
- Replace the discharged battery with a good battery.




- Connect the hand tester [A] to the battery leads as shown.
- Check charging voltage with the engine running.
- ★ If the charging voltage is higher than 13.5 V, the charging system is in good condition.
- ★ If the charging voltage is lower than 13.5 V, check the following.

**Charging Voltage 14.2 ~ 14.8 V @engine speed 4000 r/min(rpm)**



- Ground the F terminal [A] of the regulator to the engine with an auxiliary wire.
- Start the engine, and check the charging voltage with the engine running.
- ★ If the charging voltage is higher than 13.5 V, check the regulator.
- ★ If the charging voltage is lower than 13.5 V, check the following.
  - Stator Coil
  - Rotor Coil
  - Slip Rings
  - Carbon Brushes
  - Rectifier



**Test No. 2-Battery Overcharged**

- Check the regulator and/or rotor.
- ★ Repair or replace the damaged parts.

**Test No. 3-Noise**


- Check the alternator chain slack and adjust it if necessary (see Crankshaft/Transmission chapter).
- Check the alternator shaft ball bearings.
- Check the alternator ball bearings, stator coil, and/or rectifier if the alternator makes a noise.
- ★ Repair or replace the damaged parts.

**Stator Coil Inspection**

- Connect the hand tester (x 1 Ω range) between the coil leads and read the tester.
- ★ If the tester does not read as specified, replace the alternator frame.

**Stator Coil Resistance : 1.0 Ω or less**

- Using the highest hand tester range, measure the resistance between the stator coil core and each of the coil windings.
- ★ If there is any reading at all, the stator coil winding has a short and the alternator frame must be replaced.




**Rotor Coil Inspection**

- Connect the hand tester (x 1 Ω range) between the slip rings [A] and read the tester.
- ★ If the tester does not read as specified, replace the rotor [B].

**Rotor Coil Resistance: 2.3 ~ 3.5 Ω**

- Using the highest tester range, measure the resistance between the rotor shaft [C] and each of the slip rings.
- ★ If there is any reading at all, the rotor coil has a short and must be replaced.



**Slip Ring Cleaning**


- Measure the slip ring diameter.
- Visually inspect the slip ring for dirt or pitting.
- ★ If necessary, smooth the slip ring with No. 300 ~ No. 500 emery cloth.

### Slip Ring Diameter

- Measure the slip ring diameter.
- ★ If the measurement is less than the service limit, replace the rotor [A].

#### Slip Ring Diameter

Standard: 14.4 mm  
Service Limit: 14.0 mm




### Carbon Brush Length

- Measure the length [A] of both carbon brushes that stick out of the holder.
- ★ If either one is worn down to less than the service limit, replace it.

#### Carbon Brush Length (projected portion)

Standard: 10.5 mm  
Service Limit: 4.5 mm



### Rectifier Inspection


- Set the hand tester to the 1 k $\Omega$  range.
- Zero the hand tester, and connect it to each terminal [A] to check the resistance in both directions.
- The resistance should be low in one direction and more than ten times as much in the other direction. If the rectifier [B] shows low or high in both directions, the rectifier is defective and the rectifier must be replaced.

#### NOTE

- The actual meter reading varies with the meter used and the individual rectifier, but, generally speaking, the lower reading should be from zero to one half the scale.

#### CAUTION

If a megger or a meter with a large-capacity battery is used, the rectifier will be damaged.



### Regulator Inspection

- Prepare testing tools.
  - Test light: Bulb rated 12 V 3.4 W
  - Batteries: Two 12 V batteries
  - Test wires: Three auxiliary wires

#### CAUTION

The test light works as an indicator and also a current limiter to protect the regulator from excessive current. Do not use an ammeter instead of a test light.

- Connect the test light and the 12 V battery to the regulator [A] as shown.
- The test light should go on at this time.

**CAUTION**




Do not contact the regulator metal case with the wires from the battery (+) or (-) terminal during the test.

- ★ If the test light does not go on, the regulator is damaged and must be replaced.

- Connect the test light and two 12 V batteries to the regulator as shown.
- The test light should not go on at this time.

- ★ If the test light goes on, the regulator is damaged and must be replaced.

- Set the hand tester (special tool) to the 1 kΩ range.
- Check the resistance between IG and F terminals in both directions.
- ★ If the reading shows zero or infinity (no reading) in both directions, the regulator is defective and must be replaced.



*Alternator Ball Bearing Inspection*

**CAUTION**


Do not disassemble the alternator for bearing inspection since disassembling the alternator damages the bearings.

- Turn the alternator shaft back and forth while checking for plays, roughness or binding of bearings.
- ★ If bearing play, roughness, or binding is found, disassemble the alternator and replace the bearings.



Alternator Circuit

EC102



- 1. Alternator
- 2. Rotor
- 3. Carbon Brush
- 4. Stator Coil

- 5. Regulator
- 6. Rectifier
- 7. Ignition Switch
- 8. Main Fuse 30A

- 9. Battery
- 10. Load